



Assembly Instructions

DIY Bench Ends

Read these instructions and general information to properly and safely assemble the DIY Bench Ends.

May 14, 2019
Revision 01

5701-00100F-xx-xx

Contents:

2 bench ends

Required (not included):

5 equal lengths of 2x4 lumber (maximum 5')

10 deck screws (3.5" long)

Drill

Please contact RTS Companies for any questions or concerns

RTS Companies

1.800.663.2803 (CAN)

1.888.641.3077 (USA)

info@rtscompaniesinc.com

Method:



1. Tools: Drill, 10 Deck Screws (3.5"), 5 pieces of 2x4 lumber (up to 5' long).



2. Lay one of the bench ends on the ground and insert each of the pieces of lumber into the slots. Make sure the wood is flush with the outer side of the bench end.



3. Drill 1 screw into each section, through the wood. Do not overtighten.



4. Place second bench end over pieces of wood. Ensure the wood is flush with the outer side of the bench end.



5. Drill 1 screw into each section, through the wood. Do not overtighten.



6. Grab your favourite beverage and enjoy your view!